

FLYINGVOICE

FlyingVoice

VoIP & Networking Made Easy



Web: www.flyingvoice.com

Email: sales1@flyingvoice.com

Number: 755-26099365(to-6862)



Chapter 1

IP Phone

Intergration

Solution




01

With years of development experience and technology accumulation, Flyingvoice has more than **20** technology partners and actively develops market cooperation. And through the strong SIP compatibility ability, it has reached compatibility with many PBXs



Cisco BroadWorks Integrated Solution

Auto-provisioning the Phone with Broadworks



Identity/Device Profile Add
Add a new group identity/device profile.

(3) OK Cancel

(1) Group: Flying_voice>%Flying_voice_group1
* Identity/Device Profile Name: P21W
Identity/Device Profile Type: Flyingvoice_FIP11C
Protocol: SIP 2.0
Host Name/IP Address: 001F24384A1 Port: 5060
Transport: UDP
MAC Address:
Serial Number:
Description:
Outbound Proxy Server:
STUN Server:
Physical Location:

Authentication
☐ Use Identity/Device Profile Type Credentials
(2) ☒ Use Custom Credentials
* Device Access User Name: test
* Device Access Password:
* Re-type Device Access Password:

OK Cancel

Detailed configuration instructions:

<https://www.flyingvoice.com/Uploads/detail/2024-01-02/6593a979a3a7f.pdf>

How to Use BroadWorks Features

Function
Cisco Broadworks Auto-provisioning Configuration Guide(By RPS Mode)
Cisco Broadworks Docking Configuration manual
Cisco BroadWorks Call Recording Configuration Guide
Cisco BroadWorks Flexible Seating Configuration Guide
Cisco BroadWorks Hoteling Configuration Guide
Cisco BroadWorks Priority Alert Configuration Guide
Cisco BroadWorks BLF List Configuration Guide
Cisco BroadWorks Feature Synchronization Configure Guide
Cisco BroadWorks Shared Call Appearance Configuration Guide
Cisco BroadWorks Calling Line ID Delivery Blocking Configure Guide
Cisco BroadWorks Network Ad Hoc Conference Configure Guide

Detailed configuration instructions:

<https://www.flyingvoice.com/solutions/IPCiscoBroadWorks/cibroadworksshou.html>

Metaswitch Integrated Solution

Auto-provisioning the Phone with Metaswitch




Detailed configuration instructions:

<https://www.flyingvoice.com/solutions/IP-Metaswitch/metaswitchguide.html>


Yeastar Integrated Solution

Auto-provisioning the Phone with Yeastar

FLYINGVOICE



FLYINGVOICE provides **7 auto-provisioning solutions** to adapt to the user's network environment and provisioning platform environment



Detailed configuration instructions:

<https://www.flyingvoice.com/solutions/IP-Yeastar/Auto-provisioningsolution.html>

Functional Category	Function Name
Featured Function	Hot Desking Function Introduction and Configuration
	Distinctive Ringtone Introduction and Configuration
	Conference introduction and Configuration
	Paging and Intercom Introduction and Configuration

Tips:Other feature configurations is coming soon


Detailed configuration instructions:

<https://www.flyingvoice.com/solutions/IP-Yeastar/configurationguide.html>

SAS Solution

SAS Solution Integration with IP PBX

FLYINGVOICE




Detailed configuration instructions of SAS:
<https://docs.flyingvoice.com:9443/docs/fvsas>

Asterisk/FreePBX Integrated Solution

Asterisk+SAS Solution

FLYINGVOICE



Detailed configuration instructions:

<https://www.flyingvoice.com/solutions/IP-AsteriskFreePBX/freepbxsolution.html>


Function
FreePBX Docking Configuration Guide
Paging and Intercom Configuration Guide
Ring Group Configuration Guide
Voicemail Blasting Configuration Guide
Voicemail Configuration Guide

Detailed configuration instructions:

<https://www.flyingvoice.com/solutions/IP-AsteriskFreePBX/freepbx-ConfigurationGuide.html>

Freeswitch/Fusion Integrated Solution

Auto-provisioning the Phone with Freeswitch/Fusion FLYINGVOICE



The screenshot shows the FusionPBX web interface. The top navigation bar includes links for Home, Accounts, Dialplan, Applications, Status, and Advanced. The 'Accounts' menu is expanded, showing options for Devices, Extensions, Gateways, and Users. The 'Devices' section is active, displaying a table of registered devices. A red box highlights the '+ ADD' button in the top right corner of the Devices section.


Devices (7)

Devices are endpoints that register to the system. They are added to the list manually or automatically when the device requests the provisioning information over HTTP/HTTPS.

☐	MAC Address	Label	Vendor	Template	Profiles	Enabled	Status	Description
☐	00-21-f2-2c-b7-79	1000	flyingvoice	flyingvoice/flp13g		True	05 Jan 2023 01:34:44 am https 192.168.80.187	
☐	00-21-f2-00-10-10	1001	flyingvoice	flyingvoice/g504		True	21 Dec 2022 04:00:46 am https 192.168.80.187	
☐	00-21-f2-00-00-10	1002	yealink	yealink/t56w		True	31 Oct 2023 02:58:12 am https 192.168.50.80	
☐	00-21-f2-3f-f7-cd	P10	flyingvoice	flyingvoice/p10p		False	15 Dec 2022 01:06:35 am http 192.168.78.7	
☐	00-21-f2-44-c7-99	p20G	flyingvoice	flyingvoice/p20g		True	31 Oct 2023 05:00:41 am https 192.168.11.146	
☐	00-21-f2-43-85-39	P23GW	flyingvoice	flyingvoice/p23gw		True	01 Nov 2023 07:17:03 am https 192.168.10.228	
☐	00-21-f2-00-10-11	x3	flyingvoice	fanvil/x3g		True		

Detailed configuration instructions:

<https://www.flyingvoice.com/solutions/IP-FreeswitchFusion/fusionpbx-ConfigurationGuide.html>



Detailed configuration instructions:

<https://www.flyingvoice.com/solutions/IP-FreeswitchFusion/sasfusinpbx.html>

Function
Fusion PBX Conference Centers Configuration Guide
Fusion PBX Conference Profiles Configuration Guide
Fusion PBX Conference Controls Configuration Guide
Fusion PBX Conferences Configuration Guide
Fusion PBX Auto-provisioning Configuration Guide(By RPS Mode)
Fusion PBX CallFlows Configuration Guide

Detailed configuration instructions:

<https://www.flyingvoice.com/solutions/IP-FreeswitchFusion/fusionpbx-ConfigurationGuide.html>